



# **OO Gauge Aggregate/Coal Hoppers**


Assembly Guide






# Ramp Assembly Guide

---













- Front Walkway Assembly Guide




























- Main frame assembly Guide
















Make sure that the slide moves freely  
after gluing together so the hopper  
door will open & close




















Make sure that the hopper door slide  
faces the correct direction





The hoppers can either be  
glued in place or left free to  
enable removal



The hopper doors are  
designed to be able to  
open & Close





